

Motion-Sensing Bathroom Light INSTALLATION

BATTERY INSTALLATION:

Remove the cover on the back of the light and install 3 AAA batteries (not included), noting polarity.

TOILET MOUNTING:

Ensure the flexible arm is securely attached into the port above the battery compartment. Bend the flexible arm to form a right angle and securely hook it onto the rim of the toilet bowl. The base of the light will sit outside of the toilet while the arm sits inside.

Note: Make sure that the arm is securely attached before letting go.

WALL MOUNTING:

Remove the flexible arm by sliding it downwards and gently pulling out. Use the keyhole mounts on the base and screws (included) to mount it onto a wall or other flat surface.

Note: Ensure that the mounting location is a dry location and capable of supporting the light.

OPERATION

MOTION SENSING:

This light features both motion sensors and dusk-to-dawn activation. While in low light conditions, the light will automatically turn on when motion is detected within 15ft. and in a 120-degree field. The light will turn OFF after 60 seconds (1 minute) of inactivity.

COLOR SELECT:

Press the button on the front of the light to change the color of the LED inside the toilet bowl. There are multiple options:

1. Color-changing mode
2. Stop on the current/your favorite color
3. Color-select mode (multiple solid colors to choose from)
4. Color-theme one (fades between blue, green, yellow)
5. Color-theme two (fades between pink, red, purple, orange)

AMBER GUIDE LIGHT:

The light's base produces a warm amber glow. To turn this feature ON/OFF, hold the button down for three seconds. The LEDs will flash quickly to signify that the new change is applied.

Note: Only the small LED on the end of the flexible arm is color changing. The light on the base of the light only produces an amber glow.

CLEANING INSTRUCTIONS:

Clean the light by wiping with a clean, damp cloth. Do not spray cleaning solution directly onto the light, immerse it in water or place it under running water.

MADE IN CHINA


KEYHOLE CENTER MARK
Marca central de agujero



KEYHOLE CENTER MARK
Marca central de agujero



1 5/8"
41.275 mm



⚠ WARNING

- BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY OR PRODUCT DAMAGE.
- DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES.
- REPLACE ALL BATTERIES AT THE SAME TIME.
- REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIOD OF TIME.
- DO NOT IMMERSE IN WATER.
- CLEAN WITH A SOFT DAMP CLOTH ONLY.