



The diagrams illustrate the components of the smart glasses from three perspectives:

- Front View (Left):**
 - Kamera (Camera) - four locations on the front of the glasses.
 - Blesk (Flashlight) - located on the right temple.
- Top View (Middle):**
 - Nabijący port (Charging port) - located on the top of the right temple.
 - Indykator (Indicator Light) - located on the top of the right temple.
- Side View (Right):**
 - Tłaczko 1 (Button 1) - located on the right temple.
 - Tłaczko 2 (Button 2) - located on the right temple.
 - Tłaczko 3 (Button 3) - located on the right temple.

Taste 2:
Im eingeschalteten Zustand wecken Sie mit einem einmaligen Druck den Kf-Sprachassistenten.
Im eingeschalteten Zustand aktivieren Sie durch zweimaliges schnelles Drücken die schnelle Kartelanzeige.
Im eingeschalteten Zustand starten Sie durch langes Drücken der Taste eine Audioaufnahme, und durch kurzes Drücken während der Aufnahme beenden Sie die Aufnahme (Standard-Aufnahmezeit ist 30 Min., optional 30 Min., 60 Min., 120 Min.). Die aufgezeichnete Audiodatei wird automatisch im lokalen Speicher des Produkts gespeichert und kann nach Verbindung mit der App auf das Mobiltelefon importiert werden (direkt über WLAN).